



For Use With **PANDUIT**
FIBER-DUCT
Routing Systems


FIBER-DUCT Mounting Brackets

Part Numbers: FTRB12, FTRB58, FLRB, FITF2X2, FITF4X4A, FITF4X4B, FLB12X15, FLB12X20, FLB58X15, FLB58X20, FLB, FLBM, FMRB, FUSB, FUSBM, FTRBE12, FTRBE12M, FTRBE58, FTRBN12, FTRBN12M, FTRBN58


INSTALLATION INSTRUCTIONS

© Panduit Corp. 2004


Printed in U.S.A.




FTRB12, FTRB58




FLRB




FITF2X2, FITF4X4A,
FITF4X4B




FLB12X15, FLB12X20
FLB58X15, FLB58X20




FLB, FLBM




FMRB



FUSB, FUSBM



FTRBE12, FTRBE12M,
FTRBE58



FTRBN12, FTRBN12M,
FTRBN58

Instruction Sheet RW52C

WORLDWIDE SUBSIDIARIES AND SALES OFFICES

17301 Ridgeland Avenue
Tinley Park, IL 60477-3901
Web Site: www.panduit.com/ncg



RACEWAY SYSTEMS DIVISION

Fax: 866-449-1702
Technical Support: 866-405-6656
E-mail: netconnsupport@panduit.com